

PREMIUM SERIES

ADAPTOR / USB CHARGER

USER GU**i**de





IMPORTANT SAFETY INFORMATION

- · This user guide contains important product operating instructions, safety and maintenance information.
- Please read the user guide fully before use.



Do not slide adaptor along the track.



Keep away from fire.



Keep away from water.



Not for outdoor use.

CARE AND MAINTENANCE

The Premium Series Adaptor and USB Charger are products of superior design and craftsmanship and should be treated with care. The following information will help you to protect your warranty coverage.


- The product is specifically manufactured to be used and stored at room temperature. (-5°C to +40°C, not exceeding an average of more than 25°C in any 24 hours period 1.
- · Keep the device dry.
- · Do not store the product in dirty, dusty areas.
- . Do not expose the product to rough handling
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean
 the product.

ADDITIONAL INSTRUCTIONS - PREMIUM USB CHARGER

- USB Charger is designed to work with most devices that have charger connectors and do not require software or proprietary USB signalling for charging.
- Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased.
- Disengage the charger from the track when not in use. Do not leave a fully charged battery connected to a powered charger as overcharging may shorten its lifetime.
- USB Charger is designed to hold devices of maximum weight 135am.
- * LISB connector cable is not included

PREMIUM

ADAPTOR



Align Locator to V-Groov Push adaptor to engage.



Turn adaptor approximately 45° clockwise. (Adaptor is now in "OFF" mode)



Insert plug into adaptor



To "ON", turn adaptor fully clockwise until a "click" sound is heard.



Adaptor is now in "ON" position. (Blue LED indicator will illuminate)



To "OFF", turn adaptor anti-clockwise slightly untill a "click" sound is heard. To disengage adaptor, turn anti-clockwise fully.

TECHNICAL SPECIFICATION

			BS3*	FR3*	GS3*	IS3*	ITA3*	ITL3*	JE3*
Hectrical	Rated Voltage	250V a.c.			•			•	
	Rated Current	6Amp							
		10Amp							
		13Amp							
		16Amp							
	Frequency	50Hz / 60Hz			•				
Size and Weight	Diameter x Depth	67 x 38 mm							
		67 x 43 mm							
		67 x 55.5 mm							
		67 x 58 mm							
	Weight (Estimated)	72grams							
		82grams							
		85grams							
Environmental	Ambient Operating Temp.	-5°C to +40°C (not to exceed an average of more than 25°C in any 24 hours period)							
	Degree of Protection	Ordinary							

Warranty 3 years subject to Eubiq Limited Warranty Stateme


* Premium Series Product Descriptions BS3 Premium British Adoptor

FR3 Premium France Adaptor GS3 Premium German Adaptor IS3-16 Premium Indian Classic Adaptor ITA3 Premium Italy Adaptor
ITL3 Premium International Adaptor
JE3 Premium Japan Adaptor

PREMIUM USB CHARGER



Align Locator to V-Groove. Push charger to engage. To "ON", turn charger 90° clockwise until a "click" sound is heard.



Charger is now in "ON" position. (Blue LED indicator will illuminate) To begin charging, connect the USB cable (not included) to your mobile device. Reverse the steps to disengage.

Inner Surface

Outer Surface







To hold device against USB charger, remove adhesive on metal plate provided and fasten it to the inner or outer surface of device battery cover.



Example shows the USB charger with mobile phone attached.

TECHNICAL SPECIFICATION

		USB3 Premium USB Charger			
Electrical	Input Voltage	AC100 - 250V ~			
	Output Voltage	DC5.0V			
	Rated Current	500mA max.			
	Frequency	50Hz / 60Hz			
Size and Weight	Diameter x Depth	67mm x 43mm			
	Weight	Est. 100grams			
Environmental	For indoor use only				
Function	USB Charger is designed to work with most devices that have USB charger connectors and do not require software or proprietary USB signaling for chargin				

Warranty

Types subject to county animed Warranty Statement

